

# LUXFETISH

## 2-IN-1 BLOWJOB AUTO SUCKER & PENIS ENLARGER PUMP

### OPERATING THE PRODUCT



### TO BEGIN:

1. Fully charge your device before use.
2. Attach your desired sleeve onto the base of the pump.
3. Insert your penis into the pump.
4. Press the **+** button to power ON the device. Press the **+/-** button to increase and decrease suction pressure.
5. Press the **🌀** button to release pressure if necessary.
6. Adjust the pressure/intensity to a comfortable level and enjoy the stimulation.
7. To power OFF your device, continuously press the - button until the device turns OFF.

**NOTICE:** It is recommended to use personal water based lubricant before using the device. Apply only minimum amount of suction necessary to achieve desired erection. Excessive suction may bruise or injure penis.

**CHARGING:** While charging, the indicator lights will cycle through repeatedly. When fully charged, the lights will remain lit. It takes approximately 2.5 hours to fully charge, for up to 2 hours of use.

**CLEANING:** The control panel should **NOT** be immersed or submerged in water. To clean, wipe with a damp cloth and let air-dry.

Detach the control panel before cleaning the tube and sleeves. Wash thoroughly in running water and avoid using hot water or any alcohol based cleaners for the sleeves.

### NOTICE:

- Avoid over-rigorous pumping.
- This product is intended for the use by a single user.
- This vacuum pump should NOT be used for more than 15 minutes continuously and should not be used within 24 hours of its use.
- Do not fall asleep while using the vacuum pump, or while under the influence of alcohol or drugs. The user needs to be in control of the product at all times.
- Consult a doctor before using the vacuum pump if the user experiences any discomfort in the genital area.
- The user must be in full control of his hands to safely use the device with the strength to push the pressure release button.

### TROUBLESHOOTING:

No Erection?	No vacuum due to air leak from poor seal	- Use more lubricant - Apply firm pressure to body - Check device for air leaks
Partial erection?	- Incorrect insert - Inexperienced in operating the device	- More practice from using the device - Use larger cylinder insert
Rapid loss of erection (no more than 5 minutes)	- Poor seal - Inadequate lubrication - Excessive pubic hair	- Apply firm pressure to the body - Trim pubic hair
Experiencing any discomfort or pain while device is in use	- Pumping too rapidly - Pulling of scrotal tissue	- Slower pumping

For more info please refer to the warning insert included.

### MODEL: LF5321



Photo de cobalto sur [www.guestremedical.ch](http://www.guestremedical.ch)

