

# LUXFETISH

## QUALITY LOVE SWING

PLAYFUL RESTRAINT SYSTEM HOLDS UP TO 300LBS / 136KG

Installation is fast and easy and requires only a few common household tools.

The eyelet bolt can be installed in two places:

1. **Into the underside wooden frame of a doorway**
2. **Into beam in the ceiling**

Installing the eyelet bolt into a doorway is easiest, but keep in mind that the doorway limits your range of motion. Installing the eyelet bolt into a strong ceiling beam is the preferred method of use. Please follow both sets of instructions carefully to ensure a safe and enjoyable use of this product.

### FOR DOORWAYS:

Locate the center of the wooden doorway and mark a spot on the underside of the doorframe and install.

### FOR CEILINGS:

Locate a beam in your ceiling using a stud finder. Make sure you have enough clearance from any surrounding walls or furniture. Find the center of the beam and mark a spot and install.

**NOTE:** The eyelet bolt is very sharp and can be screwed in by tapping the head of the bolt with a hammer and twisting the screw until all of the threads are concealed. Use the hammer claw to help turn the eyelet screw into the wood. To facilitate insertion, drill a 5/16 pilot hole first, then screw the eyelet bolt in. All of the threads should be concealed.

**CAUTION:** Once the eyelet bolt is installed, do not remove it for safety purposes. Doing so could weaken the eyelet bolt hold.

### HANGING THE SWING:

We recommend always to use the Steel Spring provided during assembly for best weight support. During two-person usage, make sure to account for the position of both partners when determining the loading weight (one partner may be on the floor, not actually hanging from the spring).

**WARNING:** When using the Steel Spring make sure to avoid putting hands on or near the spring while in use. Your fingers or other body parts may get pinched if too close!

The swing is fully adjustable and designed for your comfort. All pads, supports and stirrups can be adjusted to accommodate a variety of sexual positions easily. The hardware for the swing can also be adjusted to hang the swing any distance from the floor.

**WARNING:** Suggested weight limit not to exceed 300 lbs / 136kg. Install and use at your own risk.

